
PARTICIPANT EQUIPMENT
102_1
UI
108_1
ADJUNCT
112_1
INFO. SOURCE INDICATOR
110_1
NETWORK I/F
104_1
NETWORK
101
SOURCING SIGNALER
106_1
PARTICIPANT EQUIPMENT
102_N
UI
108_N
ADJUNCT
112_N
INFO. SOURCE INDICATOR
110_N
NETWORK I/F
104_N
SOURCING SIGNALER
106_N
100

FIG. 1